



TURN CONTROL BATH WASTE AND OVERFLOW DRAIN

INSTALLATION INSTRUCTIONS

Before installing, read entire installation instructions. Observe all local building and safety codes.

Unpack and inspect drain for any shipping damages. If you find any damages, do not install. Contact Customer Service at 1-866-855-2284. If you need assistance while installing your drain, call our Customer Service number.

We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures and plumbing. Signature Hardware accepts no liability for any damages to the floor, walls, plumbing or personal injury during installation.

TOOLS AND MATERIALS

Hacksaw

PVC Cement

Silicone Sealant

Damp Cloth

INSTALLATION

1. If needed, trim the tubes to the appropriate length with a hacksaw. Use PVC cement to attach the overflow assembly (**A**), waste shoe (**K**), and tee to the overflow tube and waste tube as shown in the installation diagram (pg.2).
2. Attach the rubber gasket (**B**) to the overflow assembly (**A**), and insert the overflow assembly into the tub overflow opening.
3. Assemble the overflow locking plate (**C**) with the internal threaded nipple (**D**).
4. Attach the control handle (**E**) to the overflow assembly, and tighten the set screw (**F**) to secure.
5. Position the waste shoe (**K**) on the bottom of the tub with the rubber gasket (**J**) in place between the tub and shoe.
6. Run a bead of silicone sealant along the bottom of the top mount strainer (**I**). Insert the strainer into the tub drain opening and secure with the threaded waste bolt (**H**). Wipe away any excess sealant with a damp cloth.
7. Insert the stopper (**G**) and adjust the height as desired.



INSTALLATION DIAGRAM

